

# How much service is right?

We have recently switched to Fullbay for tracking services and preventative maintenance. It allows us to create services specific for a truck, or component that might be used on many trucks. I have invested many hours recently in building checklists, and doing this has opened my eyes to a huge problem we need to address without delay. **Our PMs have been incomplete, by completing neither all the services required by NFPA 1910 or the services required by many manufacturers.**

Our present checklist has been in use for about 2 years. It was created using the form in NFPA 1910, Annex C.3<sup>1)</sup>

<sup>1)</sup>

for a limited time, this [share link](#) will allow you to view the table

From:

<https://brigadetek.com/> - **Brigade Tek**

Permanent link:

<https://brigadetek.com/bulletins/services?rev=1708396695>

Last update: **2024/02/19 21:38**

